

---

# Avr-Microcontrollers-in-Linux-Howto

|             | Revision History  |              |
|-------------|---|--------------|
| Revision 44 | 2009-04-20 17:13:07   | jdd          |
|             | obfuscate e-mail at the author demand   |              |
| Revision 43 | 2009-03-29 20:49:12   | ranjeeth     |
| Revision 42 | 2009-03-29 20:45:09   | jdd          |
|             | reverting after publication   |              |
| Revision 41 | 2009-03-29 20:41:59   | jdd          |
|             | edit to export docbook  |              |
| Revision 40 | 2009-03-28 21:07:57   | RickMoen     |
|             | Adjust style of mailto link to author's original preference.  |              |
| Revision 39 | 2009-03-28 21:05:45   | RickMoen     |
|             | Revert e-mail obfuscation, supply some missing punctuation, [re-]fix capitalisation, fix and clarify new run-on sentence. |              |
| Revision 38 | 2009-03-23 18:21:24   | ranjeeth     |
| Revision 37 | 2009-03-23 18:19:51   | ranjeeth     |
| Revision 36 | 2009-03-23 17:20:32   | ranjeeth     |
| Revision 35 | 2009-03-23 17:19:47   | ranjeeth     |
| Revision 34 | 2009-03-23 10:26:00   | jdd          |
|             | publishing tests  |              |
| Revision 33 | 2009-03-23 10:25:06   | jdd          |
| Revision 32 | 2009-03-23 10:24:24   | jdd          |
|             | use of macro to obfuscate e-mail  |              |
| Revision 31 | 2009-03-23 10:11:47   | jdd          |
|             | change was only to export docbook without admonitions   |              |
| Revision 30 | 2009-03-23 10:09:15   | jdd          |
| Revision 29 | 2009-03-23 10:05:07   | jdd          |
| Revision 28 | 2009-03-23 09:58:40   | jdd          |
|             | adding the wiki as link   |              |
| Revision 27 | 2009-03-23 09:53:28   | RickMoen     |
|             | Insert needed space characters into "pin9", "pin10", "pin25" constructs   |              |
| Revision 26 | 2009-03-23 09:49:05   | RickMoen     |
|             | Make markup of all the software items mentioned be consistent   |              |
| Revision 25 | 2009-03-23 09:43:40   | RickMoen     |
|             | Remove a couple of stray commas.  |              |
| Revision 24 | 2009-03-23 09:41:30   | RickMoen     |
|             | Polishing up a few last bits of punctuation   |              |
| Revision 23 | 2009-03-23 04:11:31   | ranjeeth     |
| Revision 22 | 2009-03-23 04:10:34   | ranjeeth     |
| Revision 21 | 2009-03-23 04:09:07   | ranjeeth     |
| Revision 20 | 2009-03-17 16:20:27   | ranjeeth     |
| Revision 19 | 2009-03-17 16:18:33   | ranjeeth     |
| Revision 18 | 2009-03-16 19:10:30   | RickMoen     |
|             | Fix hyperlink, fix English diction of new sentence.   |              |
| Revision 17 | 2009-03-16 18:50:19   | ranjeeth     |
| Revision 16 | 2009-03-16 11:36:49   | RickMoen     |
|             | A couple of punctuation nits  |              |
| Revision 15 | 2009-03-16 11:21:14   | RickMoen     |
|             | Corrected numerous run-on sentences, punctuation and grammar errors, and questionable idiom.                              |              |
| Revision 14 | 2009-03-15 10:27:24   | BordenRhodes |
|             | Cleaned up basic grammar and spelling   |              |
| Revision 13 | 2009-03-15 09:52:41   | jdd          |

|             |  |     |
|-------------|--|-----|
| Revision 12 | 2009-03-15 09:51:37  | jdd |
|             | add link to the manual of avr-libc                               |     |
| Revision 11 | 2009-03-14 21:47:18  | jdd |
|             | end of basic conversion  |     |
| Revision 10 | 2009-03-14 21:40:18  | jdd |
| Revision 9  | 2009-03-14 21:39:26  | jdd |
| Revision 8  | 2009-03-14 21:33:04  | jdd |
|             | add the image  |     |
| Revision 7  | 2009-03-14 21:27:59  | jdd |
| Revision 6  | 2009-03-14 21:26:48  | jdd |
| Revision 5  | 2009-03-14 21:25:13  | jdd |
|             | Firts step - conversion fro html by jdd and basic format edition |     |
| Revision 4  | 2009-03-14 21:22:37  | jdd |
| Revision 3  | 2009-03-14 21:18:25  | jdd |
| Revision 2  | 2009-03-14 21:13:09  | jdd |
| Revision 1  | 2009-03-14 21:10:33  | jdd |

## Table of Contents

|   |   |
|---|---|
| HOWTO .....                               | 2 |
| AVR Microcontrollers in Linux HOWTO ..... | 2 |
| Licence .....                             | 2 |
| What Is a Microcontroller? .....          | 3 |
| Software Required .....                   | 3 |
| Hello World .....                         | 4 |
| Author .....                              | 5 |
| Last version .....                        | 6 |

## HOWTO

**AVR Microcontrollers in Linux HOWTO**, Copyright (C) 2009 Ranjeeth p t  
(ranjeeth\_gecmail[at]yahoo[dot]com)

This HOWTO is for readers wishing to program an AVR microcontroller using a GNU/Linux machine. For burning your code, we will be using a parallel port. You may need other electronics components (like a few resistors, capacitors, parallel port connector, etc.), which can be bought from any electronics shop.

## AVR Microcontrollers in Linux HOWTO

### Licence

Permission is granted to copy, distribute, and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2, or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".

GNU Free Documentation License [http://wiki.tldp.org/LdpWikiDefaultLicence#GNUFreeDocumentationLicense]

## What Is a Microcontroller?

A microcontroller is a single-chip computer. It has internal RAM, ROM, timers, counters, interrupt circuitry, I/O ports, analog comparators, serial USARTs, analog to digital converters, watchdog timers, and a RISC architecture. When you are using a microprocessor, you cannot program it alone. You need other components, like RAM, ROM, timers, etc. For programming, you should know its architecture thoroughly: You must read the datasheet for your microcontroller.

## Software Required

**binutils:** Tools like the assembler, linker, etc.

**gcc-avr:** The GNU C compiler (cross-compiler for avr).

**avr-libc:** Package for the AVR C library, containing many utility functions.

**uisp:** A Micro In-System Programmer for Atmel's AVR MCUs (for burning code to MCUs' memory).

The following Atmel microcontrollers are supported by avr-gcc in Linux:

### at90s Type Devices

at90s2313, at90s2323, at90s2333, at90s2343, at90s4414, at90s4433, at90s4434, at90s8515, at90s8515, at90s8515, at90s8535, at90s1200.

### atmega Type Devices

atmega103, atmega603, atmega8, atmega48, atmega88, atmega8515, atmega8535, atmega16, atmega161, atmega162, atmega163, atmega165, atmega168, atmega169, atmega32, atmega323, atmega325, atmega3250, atmega64, atmega645, atmega6450, atmega128.

### attiny Type Devices

attiny22, attiny26, attiny26, attiny13, attiny13, attiny13, attiny13, attiny2313, attiny11, attiny12, attiny15, attiny28.

### Other AVR Devices

avr2, at90c8534, at86rf401, avr3, at43usb320, at43usb355, at76c711, avr4, avr5, at90can128, at94k, avr1.

**binutils:** Programs to manipulate binary and object files that may have been created for Atmel's AVR architecture. This package is primarily for AVR developers and cross-compilers.

**gcc-avr:** The GNU C compiler, a fairly portable optimising compiler that supports multiple languages. This package includes C language support.

**avr-libc:** Standard library used for developing C programs for Atmel AVR microcontrollers. This package contains static libraries, as well as needed header files.

**uisp:** Utility to program AVR chips with object code created by gcc-avr. It supports in-system programming.

You download the above packages untar, configure, and install it. If you are using Debian or Ubuntu, these packages are available in your distribution: Install them using apt or synaptic package manager.

## Hello World

We are writing **hello world** for the atmega8 microcontroller, which has a 28-pin, 8-bit, RISC architecture.

Before proceeding, have a look at this manual about `__avr-libc__` [<http://www.nongnu.org/avr-libc/user-manual/>], which will help you program better, and understand. Also, refer to the datasheets for the various AVR microcontrollers.

Here is our first program:

```
/* ledblink.c, an LED blinking program */
#include<avr/io.h>
#include<util/delay.h>
void sleep(uint8_t millisec)
{
    while(millisec)

        {
            _delay_ms(1); /* 1 ms delay */
            millisec--;
        }
}
main()
{

    DDRC |=1<<PC2; /* PC2 will now be the output pin */
    while(1)
    {

        PORTC &= ~(1<<PC2); /* PC2 LOW */
        sleep(100); /* 100 ms delay */

        PORTC |= (1<<PC2); /* PC2 HIGH */
        sleep(100); /* 100 ms delay */

    }
}
```

## Code Explanation

The GNU C compiler for the Atmel family identifies all functional units within the microcontroller with meaningful names. Thus, writing `PORTC=0xff` will result in the compiler generating machine code that writes 0xff to I/O port C, which will set all port C pins to logic high. Because ports are bidirectional, we must decide whether each pin should act as input or output. If the *i*'th bit of a register called DDRC (data direction register C) is 1, then the *i*'th pin of PORTC's *i*'th pin will be an output. Otherwise, it will act as an input pin. (Note that pin and bit numbers start at zero.) To make an LED blink, you have to make a pin high, then low. (Here, we use PORTC's 2<sup>nd</sup> port. That is, PC2 will be the 25<sup>th</sup> pin.) There should be a delay between the two. This is what the rest of the code does. For the delay, we use built-in function `_delay_ms(1)`, which causes a 1 ms delay.

## Compilation

```
avr-gcc -mmcu=atmega8 Os ledblink.c o ledblink.o
```

which will result in object file ledblink.o. Now, we will convert it to hex file, suitable for burning to the microcontroller's memory.

```
avr-objcopy -j .text -j .data -O ihex ledblink.o ledblink.hex
```

We are converting it to a hex file because, for burning the code to atmega8, we will use uisp, whose input file must be a .hex file.

Notice that you can *less* the ledblink.hex file.

```
:1000000012C02BC02AC029C028C027C026C025C0C6
:1000100024C023C022C021C020C01FC01EC01DC0DC
:100020001CC01BC01AC011241FBECFE5D4E0DEBF28
:10003000CDBF10E0A0E6B0E0EAE8F0E002C0059035
:100040000D92A036B107D9F710E0A0E6B0E001C0EC
:100050001D92A036B107E1F70CC0D2CF282FE4ECF7
:10006000F9E004C0CF010197F1F721502223D1F725
:100070000895CFE5D4E0DEBFCDDBFA29AAA9884E66A

:0A008000EDDFAA9A84E6EADFF9CF6B
:00000001FF
```

## Burning the Code

### Hardware

We will be using the parallel port for burning. First, we have to develop a burning circuit for it.

This is the circuit for the atmega8 microcontroller. Pin 9 & pin 10 are connected by a 4 MHz crystal oscillator, which is the external clock. The bottom right connector is for a parallel port.

If you are using any other microcontroller, as mentioned above, you should change accordingly. }}

You should watch for *RESET,XTAL1,XTAL2,SCK,MISO,MOSI pins*, and connect.

### Software

Now, we will burn ledblink.hex to the microcontroller.

```
uisp -dprog=dapa -dlpt=0x378
```

You should get message *Atmega8 Found*.

*dprog* is the programming method specifier, which in this case is *dapa*, i.e., Direct AVR Parallel Access. *dlpt* is for the parallel device setting, which is 0x378, the parallel port's device address.

```
uisp -dprog=dapa -dlpt=0x378 --erase
```

Will erase the microcontroller's code.

```
uisp -dprog=dapa -dlpt=0x378 --upload if=ledblink.hex
```

Will *upload* the *Input File* ledblink.hex

Notice that you can see the LED at pin 25 blinking.

## Author

Comments to: [mailto:ranjeeth\\_gecmail\[at\]yahoo\[dot\]com](mailto:ranjeeth_gecmail[at]yahoo[dot]com)

Ranjeeth Weblog [<http://ranjeethpt.wordpress.com>]

Govt Engg College Sreekrishnapuram,

Palakkad,Kerala India.

## **Last version**

You may find the last up-to-date version of this HOWTO on the LDP wiki [<http://wiki.tldp.org/Avr-Microcontrollers-in-Linux-Howto>].